



ibaPADU-S-CM

Central unit for the iba modular system

Manual
Issue 2.2

Manufacturer

iba AG
Koenigswarterstraße 44
90762 Fuerth
Germany

Contacts

Headquarters +49 911 97282-0
Support +49 911 97282-14
Engineering +49 911 97282-13
E-Mail iba@iba-ag.com
Web www.iba-ag.com

This manual must not be circulated or copied, or its contents utilized and disseminated, without our express written permission. Any breach or infringement of this provision will result in liability for damages.

©iba AG 2024, All rights reserved

The content of this publication has been checked for compliance with the described hardware and software. Nevertheless, deviations cannot be excluded completely so that the full compliance is not guaranteed. However, the information in this publication is updated regularly. Required corrections are contained in the following regulations or can be downloaded on the Internet.

The current version is available for download on our web site <http://www.iba-ag.com>.

Issue	Date	Revision	Author	Version HW/FW
2.2	06-2024	Dimension drawings, FO budget	st	v02.14.015

Windows® is a label and registered trademark of the Microsoft Corporation. Other product and company names mentioned in this manual can be labels or registered trademarks of the corresponding owners.

Certification

The product is certified according to the European standards and directives. This product meets the general safety and health requirements.

Other international and national standards were observed.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Contents

1	About this documentation	7
1.1	Target group and previous knowledge	8
1.2	Notations	8
1.3	Used symbols	9
2	About ibaPADU-S-CM	10
3	Scope of delivery	11
4	Safety instructions	12
4.1	Intended use	12
4.2	Special safety instructions	12
5	System requirements	13
6	Mounting and dismounting	14
6.1	Mounting	14
6.2	Dismounting	15
7	Device description	16
7.1	Views	16
7.2	Indicating elements	17
7.2.1	Operating state	17
7.2.2	State of digital inputs L10 ... L17	18
7.3	Control elements	18
7.3.1	Rotary switch S1	18
7.4	Communication interfaces	18
7.4.1	Fiber optic connections X10 and X11	18
7.5	Digital inputs X5	19
7.5.1	Connection diagram / pin assignment	19
7.5.2	Debounce filter inputs	20
7.6	Voltage supply X14	21
8	System integration	22
8.1	Application examples	22
8.1.1	Measuring system with ibaPDA	22
8.1.2	FO cascading	22

9	Updates	24
9.1	Update via ibaPDA	24
9.2	Auto-update of the modules	25
10	Configuration in ibaPDA	26
10.1	First steps for the configuration in ibaPDA	26
10.2	Modules in ibaPDA	28
10.2.1	PADU-S – General tab	28
10.2.2	PADU-S – Diagnostics tab.....	29
10.2.3	PADU-S – Analog tab.....	31
10.2.4	PADU-S – Digital tab.....	32
10.2.5	ibaPADU-S-CM – General tab.....	33
10.2.6	ibaPADU-S-CM – Digital tab	34
10.2.7	Diagnostic signals	35
11	Technical data	37
11.1	Main data.....	37
11.2	Declaration of conformity.....	38
11.3	Interfaces	38
11.4	Digital inputs.....	39
11.5	Dimensions	40
11.6	Connection diagrams.....	42
11.6.1	Pin assignment power supply X14	42
11.6.2	Pin assignment digital inputs X5	42
11.7	Example for FO budget calculation	43
12	Accessories	45
12.1	Backplane panels	45
12.1.1	ibaPADU-S-B4S.....	45
12.1.2	ibaPADU-S-B1S.....	48
12.2	Mounting system for central unit	50
12.2.1	ibaPADU-S-B.....	50
12.3	Mounting systems for ibaPADU-S-B4S.....	52
12.3.1	Mounting angles.....	52

12.3.2	Mounting panel 19"	54
12.3.3	Module carrier	59
12.4	Terminal blocks	60
12.5	FO cards and FO cables	61
12.6	iba software	61
13	Appendix	62
13.1	FO configuration using 32Mbit ibaNet protocol (StaticFO).....	62
13.1.1	FTP connection to the device	63
13.1.2	Configuration of 32Mbit ibaNet protocol	64
13.1.3	Features of the StaticFO function	70
13.1.4	Special features ibaPADU-S-CM chain	71
13.1.5	Signal list file	71
13.1.6	Analyzing an invalid configuration	73
14	Support and contact.....	74

1 About this documentation

This manual describes the construction, the use and the operation of the *ibaPADU-S-CM* device.

Other documentation



For a general description of the iba modular system and additional information about layout, application and operation of the modules, please refer to the dedicated documentations.

The documentation of the iba modular system is part of the data medium "iba Software & Manuals". The documentation is also available at www.iba-ag.com in the download area.

The documentation of the iba modular system comprises the following manuals:

■ Central units

Manuals of the central units contain the following information:

- Scope of delivery
- System requirements
- Device description
- Mounting/dismounting
- Start-up
- Configuration
- Technical data
- Accessories

■ Modules

The documentations of the single modules contain specific information on the individual module. For example:

- Short description
- Scope of delivery
- Product characteristics
- Configuration
- Description of the functions
- Technical data
- Connection diagram

1.1 Target group and previous knowledge

This documentation is aimed at qualified professionals who are familiar with handling electrical and electronic modules as well as communication and measurement technology. A person is regarded as professional if he/she is capable of assessing safety and recognizing possible consequences and risks on the basis of his/her specialist training, knowledge and experience and knowledge of the standard regulations.

1.2 Notations

In this manual, the following notations are used:

Action	Notation
Menu command	Menu <i>Logic diagram</i>
Calling the menu command	<i>Step 1 – Step 2 – Step 3 – Step x</i> Example: Select the menu <i>Logic diagram – Add – New function block</i> .
Keys	<Key name> Example: <Alt>; <F1>
Press the keys simultaneously	<Key name> + <Key name> Example: <Alt> + <Ctrl>
Buttons	<Key name> Example: <OK>; <Cancel>
Filenames, paths	<i>Filename, Path</i> Example: <i>Test.docx</i>

1.3 Used symbols

If safety instructions or other notes are used in this manual, they mean:

Danger!



The non-observance of this safety information may result in an imminent risk of death or severe injury:

- Observe the specified measures.
-

Warning!



The non-observance of this safety information may result in a potential risk of death or severe injury!

- Observe the specified measures.
-

Caution!



The non-observance of this safety information may result in a potential risk of injury or material damage!

- Observe the specified measures
-

Note



A note specifies special requirements or actions to be observed.

Tip



Tip or example as a helpful note or insider tip to make the work a little bit easier.

Other documentation



Reference to additional documentation or further reading.

2 About ibaPADU-S-CM

The modular concept of the ibaPADU-S device family is designed on the basis of a backplane. You can plug on this backplane not only the central unit, but also up to 4 input/output modules. The *ibaPADU-S-CM* central unit offers 8 digital inputs.

When equipped with the right input/output modules and combined with the *ibaPDA* software, *ibaPADU-S-CM* can be used for fast applications in the fields of data capturing and recording.

Examples of applications are as follows:

- Measurement data acquisition
- Condition Monitoring
- Noise recognition and eccentricity analysis

As the device has got a robust housing, no fan and no rotating parts, it is almost free of maintenance.

3 Scope of delivery

After unpacking, check that the delivery is complete and undamaged.

The scope of delivery includes:

- Device *ibaPADU-S-CM*
- Covering caps for FO cables and USB
- 16-pin terminal block with spring terminals (digital input channels)
- 2-pin terminal block with spring terminals (power supply)
- Data medium "iba Software & Manuals"

4 Safety instructions

Observe the following safety instructions for *ibaPADU-S-CM*.

4.1 Intended use

The device is an electrical apparatus. It is only allowed to use the device for the following applications:

- Measurement data acquisition
- Applications with iba products (*ibaPDA*, etc.)

The device may only be used as defined in the technical data, see chapter ➤ *Technical data*, page 37.

4.2 Special safety instructions

Warning!



This is a class A device. This equipment may cause radio interference in residential areas. In this case, the operator will be required to take appropriate measures.

Caution!



Observe the operating voltage range

The device may not be operated at voltages exceeding +24 V DC ($\pm 10\%$). An overly high operating voltage destroys the device!

Warning!



Modules and CPU must not be attached or detached to/from the rack under voltage!

Switch off *ibaPADU-S-CM* or disconnect power supply before attaching/detaching the modules.

Note



Do not open the device! Opening the device will void the warranty!

Note



To clean the device, use a dry or slightly moistened cloth.

5 System requirements

Hardware

For operation

- Power supply 24 V DC \pm 10 %, 3 A (fully equipped)
- Backplane panel, e. g. *ibaPADU-B4S*, see ↗ *Accessories*, page 45

For parametrization of the device and for measuring:

- PC with the following minimum equipment
 - One free PCI slot, or
 - One free PCI Express slot, or
 - One ExpressCard/34 or ExpressCard/54 slot (Notebook).

On the iba homepage <http://www.iba-ag.com> you will find suitable computer systems with desktop and industrial housing.

- An FO input card of the *ibaFOB-D* type (Firmware version V2.00 build 173 or higher):
 - *ibaFOB-io-D* / *ibaFOB-io-Dexp*
 - *ibaFOB-2io-D* / *ibaFOB-2io-Dexp*
 - *ibaFOB-2i-D* / *ibaFOB-2i-Dexp* with *ibaFOB-4o-D* add-on module
 - *ibaFOB-4i-D* / *ibaFOB-4i-Dexp* with *ibaFOB-4o-D* add-on module
 - *ibaFOB-io-ExpressCard/34* or *ibaFOB-io-ExpressCard/54* (for Notebooks)
 - FO cable (bidirectional)

An overview of suitable FO cards and FO cables can be found in the "Accessories" chapter, ↗ *FO cards and FO cables*, page 61

Software

- *ibaPDA* version 6.39.15 or higher

For license examples, see chapter ↗ *iba software*, page 61

ibaPADU-S-CM

- Firmware version 02.14.015 or higher
- Hardware version A0 or higher

6 Mounting and dismounting

The following section explains how to install, connect and remove the *ibaPADU-S-CM* device. Also refer to the notes in chapter ↗ *Safety instructions*, page 12.

Caution!



Before working on or dismounting the device, disconnect it from the power supply.

6.1 Mounting

Proceed as follows to mount the *ibaPADU-S-CM* device.

1. Mount the backplane panel on an appropriate construction.
2. Connect the grounding.
3. Plug the device into the left slot.

Make sure that the guide bolts on the rear side of the device are inserted into the corresponding holes on the backplane.

4. Press the device firmly against the backplane and secure it with the fixing screws.

Note



Always screw the device and the modules tightly. Plugging or unplugging the connectors for the inputs/outputs can otherwise cause damage.



A description of how to attach the earthing for the different mounting systems can be found in chapter ↗ *Accessories*, page 45:

- Mounting with backplane panel, see ↗ *Backplane panels*, page 45
- Mounting systems for central unit only, see ↗ *Mounting system for central unit*, page 50
- Mounting systems for *ibaPADU-S-B4S*, see ↗ *Mounting systems for ibaPADU-S-B4S*, page 52

6.2 Dismounting

Proceed as follows to dismount the *ibaPADU-S-CM* device.

Caution!



Before working on or dismounting the device, disconnect it from the power supply.


1. Switch off the device.
2. Remove all cables.
3. Hold the device and remove the upper and lower fixing screw.
4. Pull the device off the module rack.

7 Device description

Here you will find views and descriptions of the device *ibaPADU-S-CM*.

7.1 Views

The following views show the operating and indicating elements, as well as the connections of the device *ibaPADU-S-CM*



1	Operating status indicators L1 ... L4	5	Connection for digital inputs X5
2	Status LED digital inputs L10 ... L17	6	Fixing screws
3	Connection power supply 24 V X14	7	Connection FO output (TX) X10
4	Rotary switch S1	8	Connection FO input (RX) X11



X23 for service purposes only

7.2 Indicating elements

Below you will find information on the indicating elements of the device *ibaPADU-S-CM*.

7.2.1 Operating state

Colored LEDs on the *ibaPADU-S-CM* device indicate the operating status of the device.

LED	State	Description
L1 Red	on	Device boots
L1 Green	flashing slowly	Device is working
	on or off	Controller halted, device "crashed", device 100 % processor load (constantly on)
	flashing quickly	System programming mode
L2 Yellow	off	No backplane access
	on	Access to I/O modules via backplane
L3 White	off	No FO reception at RX
	flashing	FO reception available, FO protocol detected, but does not match the internally set FO protocol
	on	FO reception OK
L4 Red	off	Normal state, no errors
	flashing	Fault, internal device applications are not running.
	on	Device is defective (error during booting)

Caution!



The device must not be switched off during an update or auto update as the device or the connected modules may be damaged.

Only if the green system LED L1 flashes evenly and none of the LEDs L5 ... L8 is on, the device is ready for operation or can be switched off properly.

Note

When the LED L4 indicates a failure, please contact the iba Support. Please mention the number of times, the LED L4 is flashing.

7.2.2 State of digital inputs L10 ... L17

The green LEDs indicate whether a digital input is on or off.

LED	State	Description
L10 ... L17	on	Signal ok, logical 1
	off	no signal, logical 0

For further information, see ➤ *Digital inputs X5*, page 19.

7.3 Control elements

Below you will find information on the operating elements of the device *ibaPADU-S-CM*.

7.3.1 Rotary switch S1



With the S1 rotary switch, you can define the device addresses in the FO ring.

For further information, see ➤ *FO cascading*, page 22.

7.4 Communication interfaces

Below you will find information on the communication interfaces of the device *ibaPADU-S-CM*.

7.4.1 Fiber optic connections X10 and X11

You will find the following communication interfaces on the *ibaPADU-S-CM* device:

- X11 (RX): FO receiving interface
- X10 (TX): FO transmitting interface

The device supports the 32Mbit Flex fiber optic transmission protocol. A bidirectional FO connection is required to the *ibaPDA*. A fiber optic card of type *ibaFOB-D* or *ibaFOB-Dexp* must be installed in the *ibaPDA* computer in order to receive and transmit data.

Maximum distance of fiber optic connections

The maximum distance of fiber optic connections between 2 devices depends on various influencing factors. This includes, for example, the specification of the fiber (e. g. 50/125 μm , 62.5/125 μm , etc.), or the attenuation of other components in the fiber optic cable plant such as couplers or patch panels.

However, the maximum distance can be estimated on the basis of the output power of the transmitting interface (TX) or the sensitivity of the receiving interface (RX). A model calculation can be found in chapter [➤ Example for FO budget calculation](#), page 43.


The specification of the transmission power and the reception sensitivity of the FO components installed in the device can be found in the technical data under [➤ ibaNet interface](#), page 38.

7.5 Digital inputs X5

7.5.1 Connection diagram / pin assignment

Here, you can connect eight input signals (0...7), each bipolar and electrically isolated. Each channel is connected by means of two-wire connection. Due to the reverse polarity protection, the measurement signal is indicated logically correct, even if the connection is polarity-reversed.

For further information, see [➤ Technical data](#), page 37.



7.5.2 Debounce filter inputs

Four debounce filters are available for each of the digital inputs. These can be chosen and configured for each signal independently with the I/O Manager of *ibaPDA*. The following filters can be selected:

- Off (no filter)
- Stretch rising edge
- Stretch falling edge
- Stretch both edges
- Delay both edges


For each filter, a debounce time has to be defined in μs . This debounce time can have a value between $[1 \mu\text{s} \dots 65,535 \mu\text{s}]$.

Off

The measured input signal is forwarded directly without filtering.

Stretch rising edge

The first rising edge sets the output signal (red) to logical 1 and it remains logical 1 for the set debounce time. Subsequently, the channel is transparent again and waits for the next rising edge.




Stretch falling edge

The first falling edge sets the output signal (green) to logical 0 and it remains logical 0 for the set debounce time. Subsequently, the channel is transparent again and waits for the next falling edge.




Stretch both edges

With the first edge, the output signal (ochre) follows the initial signal (blue) and keeps the logical level for the duration of the defined debounce time. Subsequently, the channel is transparent again and waits for the next (rising or falling) edge.



Delay both edges

Beginning with the first edge, the output signal (purple) blocks the input and keeps the logical value of the edge for the duration of the defined debounce time. After the debounce time has elapsed, the channel is transparent again, directly assumes the logical level of the input signal and waits for the next (rising or falling) edge.



7.6 Voltage supply X14

The external voltage supply is connected with a 2-pin connector.

Caution!



Only connect the device to an external voltage supply 24 V DC ($\pm 10\%$ unregulated)!

Pay attention to correct polarity!

8 System integration


8.1 Application examples

The figures below show examples of *ibaPADU-S-CM* combined with *ibaPDA*.

The shown examples can be integrated in other iba systems or external systems, respecting the technical requirements.


8.1.1 Measuring system with ibaPDA

The following example shows a pure measurement application (capturing, recording, analyzing), the signals are recorded with *ibaPDA*.



8.1.2 FO cascading

With 32Mbit Flex you can group up to 15 modular systems to a ring topology.



The devices are addressed via the S1 rotary switch.

Device number in the cascade	Position of rotary switch S1
Not allowed	0
1. device	1
2. device	2
...	...
14. device	E
15. device	F

Note

If the rotary switch position is "0", the connection is interrupted in delivery state. However, it is possible to configure the device with a predefined FO signal configuration using the ibaNet protocol 32Mbit when the rotary switch position is "0".

For further information see chapter ↗ *FO configuration using 32Mbit ibaNet protocol (StaticFO)*, page 62.

A cascade is possible with all devices that support the ibaNet 32Mbit Flex protocol.

9 Updates

Caution!




Do not switch off the device when an update is running. This might damage the device. Installing an update can take some minutes.

A firmware update always upgrades the entire iba modular system, i. e. the central unit and the plugged-in I/O modules. When the update is completed, the device reboots automatically.

9.1 Update via ibaPDA

Proceed as follows to update the *ibaPADU-S-CM* device via *ibaPDA*.

1. Open the *ibaPDA* I/O Manager and choose the *PADU-S* module in the module tree.
2. Click on the "Diagnostics" tab on the <Write firmware> button and choose the "paduscm_v[xx.yy.zzz].iba" update file.
3. Start the update with <OK>.



→ After the update, *ibaPADU-S-CM* reboots automatically.

→ The update is completed, when the LED L1 is flashing slowly and regularly.

9.2 Auto-update of the modules

After having mounted the modules and applied the voltage to the central unit, *ibaPADU-S-CM* detects the modules and checks the firmware version.

ibaPADU-S-CM has a so called "overall release version", i. e. the firmware version of the entire system. This version contains the current firmware version of the central unit as well as the firmware versions of the modules.

When the firmware version of a module does not match the "overall release version" of the central unit, *ibaPADU-S-CM* does an automatic up or downgrade of the module. After that the module is ready for use.

Note



The automatic upgrade or downgrade may take a few minutes. The device must not be switched off during an auto-update.

The LEDs behave during an auto-update just as during a manually installed update (LED L1 flashes rapidly, etc.). As soon as the LED L1 is flashing green, slowly and regularly, the device can be used again.

Note



The "overall release version" contains all modules known until then and the corresponding firmware versions. If a module is not yet known (i.e. it is more recent than the central unit's firmware version), this module is ignored and not displayed in *ibaPDA*.

In this case, a new update file has to be installed for the "overall release version". If you want to get the current update file, please contact the iba support.

10 Configuration in ibaPDA

With *ibaPDA*, you can configure, capture and record the analog and digital signals of the connected modules.

Note



You need an FO card with input links and output links of the FOB-D type with firmware beginning with version V2.00 (build 172). Otherwise, you need to do a firmware update. You find a description (in the *ibaFOB-D* manual) and the latest firmware on the data storage medium that is included in delivery.


10.1 First steps for the configuration in ibaPDA

You can add the *ibaPADU-S-CM* device to your configuration in *ibaPDA* using automatic detection or manually. Start *ibaPDA* and open the I/O Manager.


Adding device automatically

Prerequisite: The *ibaPADU-S-CM* device is connected and switched on.

1. Look in the I/O Manager for the link of the FOB-D card, *ibaPADU-S-CM* is connected to.
2. Right-click the link.
- A submenu opens.




3. Click on *Autodetect*.
- If *ibaPDA* detects the device automatically, the device and the connected modules are listed in the module tree.




- If *ibaPDA* does not detect the device automatically, you can add the device manually.
- Configure *ibaPADU-S-CM* and the modules, e. g. assign a name, debouncing, etc.
See chapter ↗ *Modules in ibaPDA*, page 28.
 - To apply the configuration, click <Apply> or <OK>.

Adding device manually


- Click with the right mouse button on the connection (Link) of the *ibaFOB-io-D* card, the device is connected to.
 - Select *Add module*.
- The list of the available modules is displayed.
- Select *ibaPADU-S-CM*.



- The device is displayed in the module tree.
- Drag the device to the address that is set on the device with the S1 rotary switch (Link 1 – 15 under the device), while keeping the right mouse button pressed: Position 1 – F corresponds to address 1 – 15.
 - Click on the *General* tab on *Read configuration from device*.



- The connected modules are detected automatically and displayed in the module tree.



6. Configure *ibaPADU-S-CM* and the modules, e. g. assign a name, debouncing, etc.

See chapter [➤ Modules in ibaPDA](#), page 28.


7. To apply the configuration, click <Apply> or <OK>.

10.2 Modules in ibaPDA

The device module *PADU-S* and the follow-up module *ibaPADU-S-CM* are described below.

10.2.1 PADU-S – General tab

In the *General* tab, you make the basic settings and connection settings for the *PADU-S* module.



Basic settings

Module type

Display of the module type (read only)

Locked

A locked module can only be modified by authorized users.

Enabled

Data acquisition is enabled for this module.

Name

You can enter a name for the module here.

Timebase

Specifies the acquisition time base used for *ibaPADU-S-CM* and the connected modules.

Use name as prefix

If TRUE is selected, the module name is placed in front of the signal name as prefix.

Connection**IP address**

IP address or the host name of the *ibaPADU-S-CM* device (read only).

Auto enable/disable


If the value is TRUE, the data acquisition is started even though the device is missing.

More functions**Read configuration from device**

Reads the configuration that has been stored last from the device.

10.2.2 PADU-S – Diagnostics tab

In the *Diagnostics* tab you find information about the hardware version, firmware version, FPGA version and the serial number of the central unit and the connected modules.

**<Write firmware>**

With this button it is possible to perform firmware updates. Select the update file "paduscm_v[xx.yy.zzz].iba" in the browser and start the update with <OK>.


Note

This process may take several minutes and must not be interrupted. After an update the device will be automatically rebooted.


See chapter [➤ Update via ibaPDA](#), page 24.

<Reset to factory defaults>

Using this button all settings are reset to factory defaults after having confirmed the following request with <Yes>.



After the reset the following message appears and the device will be automatically rebooted:



10.2.3 PADU-S – Analog tab

The configured analog signals and the current values for the *PADU-S* module are displayed in the *Analog* tab.

Note



The *Analog* tab is only displayed when acquisition with analog input modules has been started.

Name	DataType	Actual
Source: (7) ibaMS16xAI-10V		
[7:0] Signal 1	INT	0
[7:1] Signal 2	INT	0
[7:2] Signal 3	INT	0
[7:3] Signal 4	INT	0
[7:4] Signal 5	INT	0
[7:5] Signal 6	INT	0
[7:6] Signal 7	INT	0
[7:7] Signal 8	INT	0
[7:8] Signal 9	INT	0
[7:9] Signal 10	INT	0
[7:10] Signal 11	INT	0
[7:11] Signal 12	INT	0
[7:12] Signal 13	INT	0
[7:13] Signal 14	INT	0
[7:14] Signal 15	INT	0
[7:15] Signal 16	INT	0
Source: (8) ibaMS3xAI-1A/100A		
[8:0] Channel 0: 6,25A max	INT	0
[8:1] Channel 1: 6,25A max	INT	0

0 256 512 768 1024 1280 1536 1792 ∞ **230** OK Apply Cancel


10.2.4 PADU-S – Digital tab

The configured digital signals and the current values for the *PADU-S* module are displayed in the *Digital* tab.

Note




The *Digital* tab is only displayed when acquisition with digital input modules has been started.



10.2.5 ibaPADU-S-CM – General tab

In the *General* tab, you make the basic settings for the *ibaPADU-S-CM* module.



Basic settings


Module type, Locked, Enabled, Name, Timebase, Use name as prefix

See chapter [Basic settings](#), page 28

Module no.

Logical module number for unambiguous referencing of signals, e.g. in expressions and *ibaAnalyzer*

10.2.6 ibaPADU-S-CM – Digital tab




Name

You can enter a signal name and additionally two comments when clicking on the  symbol.

Debounce filter

In the drop-down menu, you can choose the operating mode for the debounce filter.



See chapter  *Debounce filter inputs*, page 20.

Debounce time (µs)

Here, you can define the debounce time in µs.

Active

Enabling/disabling the signal


Note



Configure the plugged analog and digital modules. The description can be found in the documentation for the respective modules.


10.2.7 Diagnostic signals

Diagnostics signals are available in the *Diagnostics* module and can be additionally recorded. The module must be manually added. Right-click the *PADU-S* module in the module tree and select *Diagnostics* from the context menu.



10.2.7.1 Diagnostics – General tab

In the *General* tab make the basic settings for diagnostic modules.




Basic settings

Module Type, Locked, Enabled, Name, Module No., Use name as prefix

See chapter [Basic settings](#), page 28.


Timebase

The timebase is related to the general acquisition timebase of the *ibaPDA* system. The time base in the diagnostic module cannot be faster than the general acquisition time base.



10.2.7.2 Diagnostics – Digital tab

You can activate the diagnostic signals individually in the *Digital* tab.



Meaning of the signals:

Signal	Meaning
Hardware state	Indicates whether the I/O module is ready for operation.
Hardware available	Indicates whether the I/O module has been detected and initialized properly during startup.
Embedded application state	Signal not available.
Embedded application started	Signal not available.

11 Technical data

In the following you will find the technical data and dimensions for *ibaPADU-S-CM*.

11.1 Main data

Short description

Name	ibaPADU-S-CM
Description	Central unit for modular data acquisition system
Order number	10.124030

Supply

Power supply	24 V DC \pm 10 %, not stabilized, 200 mA (without I/O modules), 3 A (with I/O modules)
Power consumption max.	5 W

Operating and indicating elements

Indicators (LEDs)	4 LEDs for operating status of the device 8 LEDs for state of digital inputs
-------------------	---

Operating and environmental conditions

Temperature range	
Operation	32 °F ... 122 °F (0 °C ... 50 °C)
Storage/transport	-13 °F ... 158 °F (-25 °C ... 70 °C)
Mounting position	Vertical, plugged into backplane bus
Installation height	Up to 6562 ft (2000 m)
Cooling	Passive
Humidity class	F, no condensation
Protection class	IP20
Certification/Standards	EMC: IEC 61326-1 FCC part 15 class A
MTBF ¹⁾	1,951,614 hours / 222 years
Dimensions (width x height x depth)	2.20 in x 8.42 in x 5.83 in (56 mm x 214 mm x 148 mm) With module rack: 9.02 in x 8.62 in x 6.14 in (229 mm x 219 mm x 156 mm)
Weight (incl. packing)	2.65 lbs (1.2 kg)

¹⁾ MTBF (mean time between failure) according to Telcordia 3 SR232 (Reliability Prediction Procedure of Electronic Equipment; Issue 3 Jan. 2011 and NPRD, Non-electronic Parts Reliability Data 2011

11.2 Declaration of conformity

Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Unique Identifier:

10.124030 ibaPADU-S-CM

10.124000 ibaPADU-S-B4S

Responsible Party - U.S. Contact Information

iba America, LLC

370 Winkler Drive, Suite C

Alpharetta, Georgia

30004

(770) 886-2318-102

www.iba-america.com

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

11.3 Interfaces

ibaNet interface

Number	1	
Version	Fiber optics	
ibaNet protocol	32Mbit Flex	
Data transfer rate	32 Mbit/s	
Sampling rate	Up to 40 kHz, freely adjustable	
Connector type	2 ST connectors for RX and TX; iba recommends the use of FO with multimode fibers of type 50/125 μm or 62.5/125 μm. For information on cable length, see chap. ↗ Example for FO budget calculation , page 43.	
Transmitting interface (TX)		
Output power	50/125 μm FO cable	-19.8 dBm to -12.8 dBm
	62.5/125 μm FO cable	-16 dBm to -9 dBm
	100/140 μm FO cable	-12.5 dBm to -5.5 dBm
	200 μm FO cable	-8.5 dBm to -1.5 dBm
Temperature range	-40 °F to 185 °F (-40 °C to 85 °C)	
Light wavelength	850 nm	
Laser class	Class 1	

Receiving interface (RX)		
Receiving sensibility ²⁾	100/140 µm FO cable:	-33.2 dBm to -26.7 dBm
Temperature range	-40 °F to 185 °F (-40 °C to 85 °C)	


11.4 Digital inputs

Number	8	
Version	Galvanically isolated, protected against reverse polarity, single ended	
Input signal	24 V DC	
Max. input voltage	±60 V permanent	
Signal level		
	log. 0	> -6 V; < +6 V
	log. 1	< -10 V; > +10 V
Input current	1 mA, constant	
Debounce filter	Optional, 4 operating modes	
Sampling rate	Up to 40 kHz, freely adjustable	
Delay	Type 10 µs	
Electrical isolation		
	Channel-channel	2.5 kV AC
	Channel-housing	2.5 kV AC
Connector type	16-pin multi-pin connector; clamp-type terminal (0.2 mm² ... 2.5 mm²), screw connection. included in delivery	

²⁾ Information on other fiber optic cable diameters not specified


11.5 Dimensions

ibaPADU-S-CM




(dimensions in mm)

ibaPADU-S-CM with cables




(dimensions in mm)

Minimum distance between 2 iba modular systems


(dimensions in mm)

11.6 Connection diagrams

11.6.1 Pin assignment power supply X14


Pin	Connection	
1	+ 24 V	
2	0 V	

11.6.2 Pin assignment digital inputs X5

Pin	Connection	
1	Digital input 00 +	
2	Digital input 00 -	
3	Digital input 01 +	
4	Digital input 01 -	
5	Digital input 02 +	
6	Digital input 02 -	
7	Digital input 03 +	
8	Digital input 03 -	
9	Digital input 04 +	
10	Digital input 04 -	
11	Digital input 05 +	
12	Digital input 05 -	
13	Digital input 06 +	
14	Digital input 06 -	
15	Digital input 07 +	
16	Digital input 07 -	

11.7 Example for FO budget calculation

A fiber optic link from an *ibaM-FO-2IO* module (FO transmitter) to an *ibaBM-PN* device (FO receiver) is used as an example.



The example refers to a P2P connection with an FO cable of type 62.5/125 μm . The light wavelength used is 850 nm.

The range of the minimum and maximum values of the output power or receiver sensitivity depends on the component and, among other things, on temperature and aging.

For the calculation, the specified output power of the transmitting device and, on the other side, the specified sensitivity of the receiving device must be used in each case. You will find the corresponding values in the relevant device manual in the chapter "Technical data" under "ibaNet interface".

ibaM-FO-2IO specification

Output power of FO transmitting interface		
FO cable in μm	Min.	Max.
62.5/125	-16 dBm	-9 dBm

ibaBM-PN specification

Sensitivity of FO receiving interface		
FO cable in μm	Min.	Max.
62.5/125	-30 dBm	

Specification FO cable

Refer to the data sheet for the fiber optic cable used:

FO cable	62.5/125 μm
Connector loss	0.5 dB connector
Cable attenuation at 850 nm wavelength	3.5 dB / km

Equation for calculating the FO budget (A_{Budget}):

$$A_{Budget} = |(P_{Receiver} - P_{Sender})|$$

$P_{Receiver}$ = sensitivity of FO receiving interface

P_{Sender} = output power of FO transmitting interface

Equation for calculating the fiber optic cable length (l_{Max}):

$$l_{Max} = \frac{A_{Budget} - (2 \cdot A_{Connector})}{A_{Fiberoptic}}$$

$A_{Connector}$ = connector loss

$A_{Fiberoptic}$ = cable attenuation

Calculation for the example ibaM-FO-2IO -> ibaBM-PN in the best case:

$$A_{Budget} = |(-30 \text{ dBm} - (-9 \text{ dBm}))| = 21 \text{ dB}$$

$$l_{Max} = \frac{21 \text{ dB} - (2 \cdot 0.5 \text{ dB})}{3.5 \frac{\text{dB}}{\text{km}}} = 5.71 \text{ km}$$

Calculation for the example ibaM-FO-2IO -> ibaBM-PN in the worst case:

$$A_{Budget} = |-30 \text{ dBm} - (-16 \text{ dBm})| = 14 \text{ dB}$$

$$l_{Max} = \frac{14 \text{ dB} - (2 \cdot 0.5 \text{ dB})}{3.5 \frac{\text{dB}}{\text{km}}} = 3.71 \text{ km}$$

Note

When connecting several devices as a daisy chain or as a ring (e.g., *ibaPADU-S-CM* with 32Mbit Flex), the maximum distance applies to the section between two devices. The FO signals are re-amplified in each device.

Note

When using fiber optics of the 50/125 µm type, a reduced distance (by approx. 30–40%) must be expected.

Note

In addition to conventional multimode cable types OM1 (62.5/125 µm) and OM2 (50/125 µm), the other cable types OM3, OM4 and OM5 of the 50/125 µm fiber can also be used.

12 Accessories

12.1 Backplane panels

12.1.1 ibaPADU-S-B4S

Backplane panel for mounting 1 central unit and up to 4 I/O modules.



12.1.1.1 Scope of delivery – ibaPADU-S-B4S

The scope of delivery of the *ibaPADU-S-B4S* backplane panel includes:


- Backplane panel
- Assembly kit



Assembly kit



12.1.1.2 Dimensions – ibaPADU-S-B4S



(dimensions in mm)

12.1.1.3 Grounding – ibaPADU-S-B4S

For grounding the backplane panel use the enclosed grounding cable and the enclosed grounding screws as shown below.



- 1 Spring lock washer
- 2 Ground wire with cable lug
- 3 Contact washer

12.1.1.4 Technical data – ibaPADU-S-B4S

Short description

Product name	ibaPADU-S-B4S
Description	Backplane panel for 1 central unit and up to 4 I/O modules from the iba modular system
Order number	10.124000

Interface central unit

Number	1
Connection technology	Female header, pole number 3 x 32
Slot	X1

Interface I/O modules

Number	4
Connection technology	Female header, pole number 3 x 32
Slot	X2 - X5

Supply

Power supply	none
--------------	------

Mounting

Housing	4 thread M6, rear side
Assembly kit	enclosed
Grounding	1 thread M6, rear side
Assembly kit	enclosed

Environmental conditions

MTBF ³⁾	47,872,504 hours / 5,464 years
Dimensions (width x height x depth)	229 mm x 219 mm x 21 mm
Weight / incl. packaging	0.66 kg / 0.85 kg

³⁾ MTBF (mean time between failure) according to Telcordia Issue 3 (SR232) Reliability Prediction Procedure of Electronic Equipment (Issue 3 Jan. 2011)

12.1.2 ibaPADU-S-B1S

Backplane panel for mounting 1 central unit and 1 I/O module.




12.1.2.1 Scope of delivery – ibaPADU-S-B1S

The scope of delivery of the *ibaPADU-S-B1S* backplane panel includes:

- Backplane panel
- Assembly kit



12.1.2.2 Dimensions – ibaPADU-S-B1S



12.1.2.3 Grounding – ibaPADU-S-B1S

See ➤ *Grounding – ibaPADU-S-B4S*, page 46.

12.1.2.4 Technical data – ibaPADU-S-B1S

Short description

Product name	ibaPADU-S-B1S
Description	Backplane panel for 1 central unit and 1 I/O module from the iba modular system; with mounting angles
Order number	10.124002

Interface central unit

Number	1
Connection technology	Female header, pole number 3 x 32
Slot	X1

Interface I/O modules

Number	1
Connection technology	Female header, pole number 3 x 32
Slot	X2

Supply

Power supply	none
--------------	------

Mounting

Housing	4 through holes M6
Assembly kit	-
Grounding	1 thread M6, rear side
Assembly kit	enclosed

Design

Dimensions (width x height x depth)	99 mm x 247 mm x 21 mm
Weight / incl. packaging	0.32 kg / 0.43 kg

12.2 Mounting system for central unit**12.2.1 ibaPADU-S-B**


Mounting panel with DIN rail clip for 1 central unit (without I/O modules).

**12.2.1.1 Scope of delivery – ibaPADU-S-B**

The scope of delivery of the mounting system for the *ibaPADU-S-B* central unit includes:

- Mounting panel

12.2.1.2 Dimensions – ibaPADU-S-B



(dimensions in mm)

12.2.1.3 Grounding – ibaPADU-S-B

The grounding must be done via the DIN rail.

12.2.1.4 Technical data – ibaPADU-S-B

Short description

Product name	ibaPADU-S-B
Description	Mounting panel for 1 central unit from the iba modular system; with DIN rail clip
Order number	10.124001

Mounting

Panel	on DIN rail according to EN 50022 (TS 35, DIN Rail 35)
Assembly kit	-
Grounding	via DIN rail
Assembly kit	-

Design

Dimensions (width x height x depth)	56 mm x 219 mm x 28 mm
Weight / incl. packaging	0.17 kg / 0.26 kg

12.3 Mounting systems for ibaPADU-S-B4S

12.3.1 Mounting angles

Mounting angles for mounting an iba modular system in a cabinet, 2 pieces, matching for *ibaPADU-S-B4S* (10.124000).


1 set (2 pieces) is needed for one backplane panel.




12.3.1.1 Scope of delivery – mounting angles

- 2 pieces mounting angles (1 set)

12.3.1.2 Dimensions – mounting angle



(dimensions in mm)



(dimensions in mm)

12.3.1.3 Technical data – mounting angle

Short description

Product name	Mounting angles for iba modular system
Description	1 set (2 pieces) mounting angles, matching for backplane panel ibaPADU-S-B4S, for a front side mounting of the backplane
Order number	10.124006

Mounting


Angle	4 through holes M6
Assembly kit	-

Design

Dimensions (width x height x depth)	179 mm x 57 mm x 10 mm
Weight / incl. packaging	0.091 kg / 0.092 kg

12.3.2 Mounting panel 19"


Mounting panel (483 mm/19") for up to 2 *ibaPADU-S-B4S* backplane panels.



12.3.2.1 Scope of delivery – mounting panel 19"

The scope of delivery of the mounting panel includes:


- Mounting panel
- Assembly kit




12.3.2.2 Mounting backplane panel

Up to 2 *ibaPADU-S-B4S* backplane panels can be mounted on the 19" mounting panel. The mounting of one backplane panel is possible either in the center or on the right or left side.


Mounting centered



Mounting on the right



12.3.2.3 Dimensions – mounting panel 19"



(dimensions in mm)

12.3.2.4 Grounding – mounting panel 19"

The following variants are available for grounding.

Variant 1:

One backplane panel and grounding of the mounting panel are on the **same side**.

After the backplane panel is mounted on the 19" mounting panel, the backplane panel must be grounded via the mounting panel. Screw the grounding cable on the back of the mounting panel to the backplane panel. Use the screw connection, see ↗ *Grounding – ibaPADU-S-B4S*, page 46.



Connect the cable to the next threaded bolt of the mounting panel. The grounding of the mounting panel is also connected to the threaded bolt.




Both grounding cables are attached to the threaded bolt as shown.



Variant 2:


One backplane panel and grounding of the mounting panel are **not on the same side**.

The backplane panel is mounted on the right or left side of the mounting panel, the grounding of the mounting panel is connected on the respective other side. Ground the backplane panel at the next threaded bolt of the mounting panel. The grounding of the mounting panel can then be connected at the opposite side. See figure:

**Variant 3:**

Two backplane panels are mounted.

Ground the two backplane panels at the next threaded bolt on the left or right. The grounding of the mounting panel must be connected to one of the threaded bolts.

Connection for grounding the 19" mounting panel

- 1 Hexagon nut/lock nut
- 2 Hexagon nut
- 3 Spring lock washer
- 4 Ground wire with cable lug
- 5 Contact washer

12.3.2.5 Technical data – mounting panel 19"

Short description

Product name	Mounting panel 19" for iba modular system
Description	Mounting panel (483 mm/19") for up to 2 <i>ibaPADU-S-B4S</i> backplane panels
Order number	10.124005

Mounting


Panel	4 through holes
Assembly kit	enclosed
Grounding	2 threaded bolts M6, rear side
Assembly kit	enclosed

Design

Height units (HU)	5
Dimensions (width x height x depth)	483 mm x 221 mm x 22 mm
Weight / incl. packaging	1.2 kg / 1.4 kg

12.3.3 Module carrier

Module carrier for mounting 1 backplane panel *ibaPADU-S-B4S*.



Module carrier with power supply

The included table power supply can be conveniently stored in the bottom of the module carrier.

12.3.3.1 Scope of delivery – module carrier

The scope of delivery for the module carrier includes:

- Module carrier
- Table power supply 24 V DC / 5 A

12.3.3.2 Dimensions – module carrier

Width x height x depth: 230 mm x 435 mm x 200 mm

12.3.3.3 Technical data – module carrier

Short description

Product name	Module carrier for iba modular system
Description	Module carrier for mounting 1 backplane panel <i>ibaPADU-S-B4S</i> ; incl. power supply 24 V DC / 5 A (10.800007)
Order number	10.124007



Design

Dimensions (width x height x depth)	230 mm x 435 mm x 200 mm
Weight	1.8 kg

Accessories

Power supply 24 V DC / 5 A	10.800007
----------------------------	-----------

12.4 Terminal blocks

12 pin RM 3.81 terminal block PHOENIX		
Order number	52.000024	
2 pin RM 5.08 terminal block WAGO		
Order number	52.000022	

12.5 FO cards and FO cables

Below you will find an overview of suitable FO cards and FO cables for the operation of *ibaPADU-S-CM*.

Product	Order no.	Remark
ibaFOB-io-D	11.115810	PCI card (1 input, 1 output)
ibaFOB-2i-D	11.115710	PCI card (2 inputs)
ibaFOB-2io-D	11.115800	PCI card (2 inputs, 2 outputs)
ibaFOB-4i-D	11.115700	PCI card (4 inputs)
ibaFOB-4o-D		Extension module (4 outputs)
- For PCI slot (long)	11.116201	For all <i>ibaFOB-D</i> cards as output module or for mirroring the inputs
- For rackline slot (short)	11.116200	
ibaFOB-io-Dexp	11.118020	PCI-Express card (1 input, 1 output)
ibaFOB-2i-Dexp	11.118030	PCI-Express card (2 inputs)
ibaFOB-2io-Dexp	11.118010	PCI-Express card (2 inputs, 2 outputs)
ibaFOB-4i-Dexp	11.118000	PCI-Express card (4 inputs)
ibaFOB-io-ExpressCard	11.117000	For measuring with the notebook
ibaFOB-io-USB	11.117010	For measuring with the notebook

iba also offers suitable FO cables in different designs and lengths. Here is an example of a common cable in duplex and 5 m length.

Product	Order no.	Remark
FO/p2-5	50.102050	5 m duplex FO cable

Note



In addition to conventional multimode cable types OM1 (62.5/125 µm) and OM2 (50/125 µm), the other cable types OM3, OM4 and OM5 of the 50/125 µm fiber can also be used.

12.6 iba software

Below you will find license examples for data acquisition with *ibaPDA* and data analysis with *ibaAnalyzer*.

Product	Order no.	Remark
ibaPDA-1024	30.771024	For up to 1024 signals
ibaPDA-2048	30.772048	For up to 2048 signals
ibaAnalyzer	33.010000	Offline- and online analysis software with free license if used to analyze *.dat files generated by licensed iba software.

You can find further accessories in our online catalog at www.iba-ag.com.

13 Appendix

13.1 FO configuration using 32Mbit ibaNet protocol (StaticFO)

The central unit *ibaPADU-S-CM* supports basically the ibaNet protocol 32Mbit Flex. The rotary switch position can be 1...15 (1...F) depending on the device address.

When the rotary switch is set to "0", it is possible to use the FO connection with 32Mbit protocol and a fixed FO configuration. This function is also called "StaticFO" in short.

Using the fixed configuration, the IO signals are copied 1:1 to the fiber optics according to the slot order (slot X1 ... X5) the I/O modules are installed.

The fixed order in the FO configuration can be shifted with a configurable offset.

In addition, up to 16 *ibaPADU-S-CM* systems can be connected in a chain to *ibaPDA*, with each system being assigned a predefined range with a smaller size on the fiber optic cable (slot or container).

In 32Mbit mode, the signals can be recorded in *ibaPDA* with a FOB Fast module. A connection to an *ibaLogic-V5* system or to another iba hardware device with 32Mbit protocol is also possible.

Note



The configuration "StaticFO-IO" is activated in delivery state.

With this default configuration, it is possible to replace existing *ibaPADU-S-IT-05* systems. These systems are also called "ibaPADU-S-IT in IO mode", the official designation is *ibaPADU-S-IT-05-SMS-interface* (10.124018).

To ensure that the I/O modules used with *ibaPADU-S-IT-05* can also be used with the new central unit *ibaPADU-S-CM*, an upgrade must be installed for the I/O modules at iba. Therefore the modules need to be sent to iba. Please contact the iba support for this purpose.

When using *ibaPADU-S-CM*, the *ibaPDA* version and configuration can remain unchanged. However, the only exception is, that the offset of the 8 digital inputs (8xDI) will change:

- old (with *ibaPADU-S-IT-05*): 0xC0 Bit0 to Bit7
- new (with *ibaPADU-S-CM*): 0xC0 Bit8 to Bit15

If you want to use another FO configuration of the ibaNet protocol 32Mbit, it is necessary to establish an FTP connection to the device and to modify the configuration file [Config_StaticFO.xml](#) accordingly. The existing configuration file must be overwritten.

13.1.1 FTP connection to the device

In order to establish an FTP connection to the *ibaPADU-S-CM* device proceed as follows:

1. Connect the device to the computer via an USB cable.

The USB interface is located at the bottom of the device. A type A to B USB cable is required. A suitable cable is available at iba on request.

2. As soon as the computer is connected for the first time to the device, the "Found New Hardware Wizard" will show up and the driver for the USB connection has to be installed.

You find the driver on the data medium "iba Software & Manuals" in this directory:

[\02_iba_Hardware\ibaPADU-S-CM\USB_Driver](#)

→ After having installed successfully, an additional network connection is available with the device name "IBA AG USB Remote NDIS Network Device".

3. A fixed IP address must be assigned to this interface. The address has to be from this range: 192.168.0.n with n = 2...254 and the subnet mask 255.255.255.0.

Example:

IP: 192.168.0.2

SubNet: 255.255.255.0


4. Now, you can establish an FTP connection to the device.

You may use a FTP client or the Windows File Explorer. In both cases, the address is "192.168.0.1" and the user is "anonym" without any password.

Example: Windows File Explorer:




→ The following files are displayed in the file window:



13.1.2 Configuration of 32Mbit ibaNet protocol

Copy the file `Config_StaticFO.xml` to your computer and open the file with an editor.



```
<?xml version="1.0" encoding="utf-8"?>
<Module Name="StaticFO" xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance">
  <ModuleInfo>
    <Description>Configuration for StaticFO (32Mbit fixed configuration i.s.o. Flex)</Description>
    <UserText/>
    <LockedBy/>
  </ModuleInfo>
  <Properties Name="Selection">
    <!-- Select, which of the following <Properties Name="xxx"/> should be used. -->
    <!-- Use Value="None" to disable StaticFO -->

    <Property Name="SelectedConfiguration" Value="StaticFO-I0"/>

  </Properties>
  <Template Name="">
  </Template>
  <Properties Name="StaticFO-I0">
  </Properties>
</Module>
```

The two green marked regions describe a template for the configuration and the default configuration "StaticFO-I0" configuration of the ibaNet protocol 32Mbit.

The template provides a short description of the required properties.

The blue marked entry "Value" determines the currently active configuration.

The XML configuration file may include several configurations with different names. But only the configuration specified with "Value" is active.

In order to create a new configuration, proceed as follows:

1. Copy either the template or the existing configuration "StaticFO-I0" and paste it at the end of the file:


```

<Properties Name="StaticFO-IO">
  <!-- Configuration for FO mode INT 64A+64D -->
  <!-- Replacement of ibaPADU-S-IT-05 with IO mode -->

  <Property Name="FO_Signals" Value="Int64"/>
  <Property Name="FO_Slot" Value="0"/>
  <Property Name="FO_Period" Value="50" Unit="us"/>

  <Property Name="FO_IN_AO_Offset" Value="0"/>
  <Property Name="FO_IN_DO_Offset" Value="0"/>
  <Property Name="FO_OUT_AI_Offset" Value="0"/>
  <Property Name="FO_OUT_DI_Offset" Value="0"/>

  <Property Name="Use_ibaPADU-S-CM_DI" Value="true" />
  <Property Name="Use_Output_StatusSignals" Value="false" />
  <Property Name="Use_Output_ControlSignals" Value="false" />
  <Property Name="HF_Compatibility" Value="true" />
  <Property Name="Debounce_Delay_Time_32xDI_16xDIO" Value="0" Unit="us"/>
</Properties>

<Properties Name="StaticFO-IO">
  <!-- Configuration for FO mode INT 64A+64D -->
  <!-- Replacement of ibaPADU-S-IT-05 with IO mode -->

  <Property Name="FO_Signals" Value="Int64"/>
  <Property Name="FO_Slot" Value="0"/>
  <Property Name="FO_Period" Value="50" Unit="us"/>

  <Property Name="FO_IN_AO_Offset" Value="0"/>
  <Property Name="FO_IN_DO_Offset" Value="0"/>
  <Property Name="FO_OUT_AI_Offset" Value="0"/>
  <Property Name="FO_OUT_DI_Offset" Value="0"/>

  <Property Name="Use_ibaPADU-S-CM_DI" Value="true" />
  <Property Name="Use_Output_StatusSignals" Value="false" />
  <Property Name="Use_Output_ControlSignals" Value="false" />
  <Property Name="HF_Compatibility" Value="true" />
  <Property Name="Debounce_Delay_Time_32xDI_16xDIO" Value="0" Unit="us"/>
</Properties>

:./Module>

```



2. Edit the copied part according to the new configuration. At first, enter a new, unambiguous configuration name.

```

<Properties Name="StaticFO-IO">
  <!-- Configuration for FO mode INT 64A+64D -->
  <!-- Replacement of ibaPADU-S-IT-05 with IO mode -->

  <Property Name="FO_Signals" Value="Int64"/>
  <Property Name="FO_Slot" Value="0"/>
  <Property Name="FO_Period" Value="50" Unit="us"/>

  <Property Name="FO_IN_AI_Offset" Value="0"/>
  <Property Name="FO_IN_DO_Offset" Value="0"/>
  <Property Name="FO_OUT_AI_Offset" Value="0"/>
  <Property Name="FO_OUT_DI_Offset" Value="0"/>

  <Property Name="Use_ibaPADU-S-CM_DI" Value="true" />
  <Property Name="Use_Output_StatusSignals" Value="false" />
  <Property Name="Use_Output_ControlSignals" Value="false" />
  <Property Name="HF_Compatibility" Value="true" />
  <Property Name="Debounce_Delay_Time_32xDI_16xDIO" Value="0" Unit="
</Properties>

<Properties Name="StaticFO-UserDefined">
  <!-- Configuration for FO mode INT 64A+64D -->
  <!-- Replacement of ibaPADU-S-IT-05 with IO mode -->

  <Property Name="FO_Signals" Value="Int64"/>
  <Property Name="FO_Slot" Value="0"/>

```

3. After that, configure the different properties:

```
<Property Name="FO_Signals" Value="Int64"/>
```

Allowed values:

Point-to-point connection (uni- or bidirectional):

Int64	for 64 analog INT and 64 digital signals
Int128	for 128 analog INT and 128 digital signals
Int256	for 256 analog INT and 256 digital signals
Int512	for 512 analog INT and 512 digital signals
Int1024	for 1024 analog INT and 1024 digital signals
Real32	for 32 analog REAL and 32 digital signals
Real64	for 64 analog REAL and 64 digital signals
Real128	for 128 analog REAL and 128 digital signals
Real256	for 256 analog REAL and 256 digital signals
Real512	for 512 analog REAL and 512 digital signals

Chain (unidirectional):

Int16x8	for 8 analog INT per slot
Int16x64	for 64 analog INT and 64 digital signals per slot
Real16x32	for 32 analog REAL and 32 digital signals per slot

```
<Property Name="FO_Slot" Value="0" Unit=""/>
```

Only relevant when configuring a chain:

Specifies the corresponding slot of the *ibaPADU-S-CM* system.

At least: 0 (default)

Allowed values: 0 ... 15

<Property Name="FO_Period" Value="50" Unit="us"/>

This value depends on the configured/required number of signals (FO_Signals):

50	Int64A+64D	Real32A+32D	-
100	Int128A+128D	Real64A+64D	Int16x8
200	Int256A+256D	Real128A+128D	-
400	Int512A+512D	Real256A+256D	-
800	Int1024A+1024D	-	Int16x64
1000	-	Real512A+512D	Real16x32

The following four properties describe the offset of the signals in the FO configuration:

- <Property Name="FO_IN_AO_Offset" Value="0"/>
 - <Property Name="FO_IN_DO_Offset" Value="0"/>
 - <Property Name="FO_OUT_AI_Offset" Value="0"/>
 - <Property Name="FO_OUT_DI_Offset" Value="0"/>
- <Property Name="FO_Period" Value="50" Unit="us"/>

This value depends on the configured/required number of signals (FO_Signals):

The following four properties describe the offset of the signals in the FO configuration:

- <Property Name="FO_IN_AO_Offset" Value="0"/>
- <Property Name="FO_IN_DO_Offset" Value="0"/>
- <Property Name="FO_OUT_AI_Offset" Value="0"/>
- <Property Name="FO_OUT_DI_Offset" Value="0"/>

The following items must be observed:

- Allowed values: 0 ... FO_Signals-1 (e.g. Int64: 0 ... 63)
- Digital inputs and outputs must be a multiple of 32
- Analog inputs and outputs must be a multiple of 2 in INT mode

<Property Name="Use_ibaPADU-S-CM_DI" Value="true" />

The 8 digital inputs (8xDI) of the central unit are used in the FO configuration

Please note that an offset of 8 bit is necessary in the FO configuration for these digital inputs:

```

*****
***   Signal lists   ***
*****

*** Fiber optic output, list of digital signals (called DI in the module)
Signal|Len|Fiber optic|PDA setting|
|bit|      |Signal|Address|bit|
-----+-----+-----+-----+
X1_DI00| 1|      D8|    0xC0| 8|
X1_DI01| 1|      D9|    0xC0| 9|
X1_DI02| 1|     D10|    0xC0|10|
X1_DI03| 1|     D11|    0xC0|11|
X1_DI04| 1|     D12|    0xC0|12|
X1_DI05| 1|     D13|    0xC0|13|

```

This offset must always be observed, even if an offset has been configured for the digital inputs:

```

<Property Name="FO_OUT_DI_Offset" Value="32"/>

of digital signals (called DI in the modules) ***
Signal|Len|Fiber optic|PDA setting|
|bit|      |Signal|Address|bit|
-----+-----+-----+-----+
X1_DI00| 1|     D40|    0xC4| 8|
X1_DI01| 1|     D41|    0xC4| 9|
X1_DI02| 1|     D42|    0xC4|10|
X1_DI03| 1|     D43|    0xC4|11|
X1_DI04| 1|     D44|    0xC4|12|

```

```
<Property Name="Use_Output_StatusSignals" Value="false" />
```

The status signals of the output modules (output signal is available) are used in the FO configuration

```
<Property Name="Use_Output_ControlSignals" Value="false" />
```

The error signals of the output modules are used in the FO configuration

```
<Property Name="HF_Compatibility" Value="false" />
```

The signals from digital input modules are combined and transmitted as analog values. For saving space, it is thus possible to map digital signals from the digital fiber optic transmission range to the analog range. However, the 8 digital inputs of the central unit remain excluded from this function if they have been activated via the "Use_ibaPADU-S-CM_DI" property.

```
<Property Name="Debounce_Delay_Time_32xDI_16xDIO" Value="0" Unit="us"/>
```

The debounce filter "Delay both edges" is parameterized for the two I/O modules ibaMS32x-DI-24V and ibaMS16xDIO-24V (see also chapter [Debounce filter inputs](#), page 20).

Allowed values: 0 ... 65535 µs, where 0 deactivates the debounce filter.

This debouncing is required for these two module types in order to be able to continue acquiring the last measured value in *ibaPDA* after the system has been switched off.

Note

Do not forget to activate your new configuration with the corresponding property at the beginning of the file:

```
</ModuleInfo>
<Properties Name="Selection">
  <!-- Select, which of the following <Properties Name="xxx"/> should be used
  <!-- Use Value="None" to disable StaticFO

  <Property Name="SelectedConfiguration" Value="StaticFO-UserDefined"/>

</Properties>
<Template Name="">

<Properties Name="StaticFO-IO">

  <Properties Name="StaticFO-UserDefined">
    <!-- Configuration for FO mode IN1 64A+64D -->
    <!-- Replacement of ibaPADU-S-IT-05 with IO mode -->

    <Property Name="FO_Signals" Value="Int64"/>
    <Property Name="FO_Slot" Value="0"/>
    <Property Name="FO_Slot" Value="0"/>
```

4. After the configuration has been finished, save the file and copy it to the device by overwriting the previous file.
5. Wait approx. 10 seconds until the file `FoSignalList.txt` has been automatically updated. If necessary refresh the display by pressing <F5>. Finally, you may copy the file to your computer.

Note

If a new file `Err_Config_StaticFO.xml` appears after 10 seconds waiting time (refresh the display with <F5>), there may be an error in the FO configuration file.

► Internet ► 192.168.0.1



Config_StaticFO.xml



Err_Config_StaticFO.xml

You find a description of analyzing the error in chapter [Analyzing an invalid configuration](#), page 73.

13.1.3 Features of the StaticFO function

13.1.3.1 Limited number of signals

Regardless of the fiber optic mode activated via the "FO_Signals" property, only a fixed number of analog and digital signals is available for transmission.

In "Real64A+64D" mode, for example, a maximum of 64 analog and 64 digital signals are available.

If your system contains more than this number of signals, surplus signals are not copied to the fiber optic and therefore cannot be captured or transmitted.

13.1.3.2 Special feature of digital modules - analog transmission of digital signals

Digital modules, no matter how many channels they have, always use a number of 32 digital signals internally.

The same applies to the 8 digital inputs of the central unit if they have been activated via the "Use_ibaPADU-S-CM_DI" property.

If the "Real64A+64D" mode is set for example and the central unit is activated, only 1 additional digital module (in slots X2 - X5) can be acquired. This also applies if the digital module has only 16 input channels.

For digital signals from modules, however, it is possible to combine these with the "HF_Compatibility" property to form analog values and transmit them in the analog range.


13.1.3.3 No power frequency signals

The signals for measuring the power frequency of the analog modules cannot be acquired or transmitted.

13.1.4 Special features ibaPADU-S-CM chain

Up to 16 *ibaPADU-S-CM* systems can be connected in a line topology (chain) with iba software or other iba components. Each fiber optic output of an *ibaPADU-S-CM* system is connected to the next fiber optic input until all devices of a line are connected to the ibaFOB card.

Setup of a line structure



Output modules cannot be operated with this structure.

The individual systems are addressed via the StaticFO configuration file in the "FO_Slot" property.

Slot 0 must always or at least be present, since this determines the fiber optic clock in the chain.

Therefore, this system must be connected at the very end, i.e. at the furthest distance from the ibaFOB card.

Restrictions in Int16x8 mode (FO_Signals):

- The acquisition of digital input signals is not possible.
- Analog input modules are only used for acquisition if they provide a maximum of 8 analog input signals.

13.1.5 Signal list file

The signal list file contains the FO configuration and the signal mapping of the installed modules. The figure below shows a signal list file using the example of a "StaticFO-IO" configuration.

```

*****
*** Fiber optic settings ***
*****
Mode: 32 Mbit Int 64A + 64D, Period: 50 us

*****
***      Signal lists      ***
*****

*** Fiber optic output, list of digital signals (called DI in the modules) ***

```

Signal	Len	Fiber optic	PDA setting
bit		Signal	Address bit
X3_DI00	1	D0	0xC0 0
X3_DI01	1	D1	0xC0 1
X3_DI02	1	D2	0xC0 2
X3_DI03	1	D3	0xC0 3
X3_DI04	1	D4	0xC0 4
X3_DI05	1	D5	0xC0 5
X3_DI06	1	D6	0xC0 6
X3_DI07	1	D7	0xC0 7
X3_DI08	1	D8	0xC0 8
X3_DI09	1	D9	0xC0 9
X3_DI10	1	D10	0xC0 10
X3_DI11	1	D11	0xC0 11
X3_DI12	1	D12	0xC0 12
X3_DI13	1	D13	0xC0 13
X3_DI14	1	D14	0xC0 14
X3_DI15	1	D15	0xC0 15

```

*** Fiber optic output, list of analog signals (called AI in the modules) ***

```

Signal	Len	Type	Fiber optic	PDA setting
bit			Signal Offset	Address
X4_AI00	16	INT	A0 0 Bytes	0x40
X4_AI01	16	INT	A1 0 Bytes	0x42
X4_AI02	16	INT	A2 0 Bytes	0x44
X4_AI03	16	INT	A3 0 Bytes	0x46
X4_AI04	16	INT	A4 0 Bytes	0x48
X4_AI05	16	INT	A5 0 Bytes	0x4A
X4_AI06	16	INT	A6 0 Bytes	0x4C
X4_AI07	16	INT	A7 0 Bytes	0x4E

```

*** Fiber optic input, list of digital signals (called DI in the modules) ***

```

Signal	Len	Fiber optic	PDA setting
bit		Signal	Address bit

The selected ibaNet protocol 32Mbit is displayed under "Fiber optic settings".

The mapping of the I/O signals and the FO configuration is shown in the signal list. The signals are subdivided according to signal type and signal direction.

The first digital signal (DI00) of the digital input module mounted on slot X3 is at the first position (D0) of the FO configuration in this case.

In another example, when an offset of 32 is configured (<Property Name="FO_OUT_DI_Offset" Value="32"/>) the corresponding bit is at the 32th position (D32) of the FO configuration.


```

*****
***      Signal lists      ***
*****

*** Fiber optic output, list of digital signals (called DI in the modules) ***

```

Signal	Len	Fiber optic	PDA setting
	bit	Signal	Address
X3_DI00	1	D32	0xC4
X3_DI01	1	D33	0xC4
X3_DI02	1	D34	0xC4
X3_DI03	1	D35	0xC4
X3_DI04	1	D36	0xC4

The given address (0xC4) is an additional information for the use with *ibaPDA*. The FOB fast module can be configured in advanced mode with this setting.

Note



If *ibaPADU-S-CM* is reset to factory defaults with *ibaPDA* and 32Mbit Flex, the 32Mbit configuration will be reset too (after power off/on). The configuration file, which might have been modified and enhanced with new entries, will be deleted and replaced by the default configuration file.

13.1.6 Analyzing an invalid configuration

If an error occurs in the configuration, the last used configuration and the last configuration file `Config_StaticFO.xml` will be restored.

Additionally, the invalid configuration will be copied into the `Err_Config_StaticFO.xml` file.

Open the file `Err_Config_StaticFO.xml` with an editor in order to analyze the error.

A note is inserted at the invalid property.

```

<Property Name="FO_Signals" Value="Int64"/>
<Property Name="FO_Period" Value="50" Unit="us"/>
<Property Name="FO_IN_A0_Offset" Value="0"/>
<Property Name="FO_IN_D0_Offset" Value="0"/>
<Property Name="FO_OUT_AI_Offset" Value="128" Error="WrongValue" ErrorNo="Value 128 is not in the range [0..63]"/>
<Property Name="FO_OUT_DI_Offset" Value="0"/>
<Property Name="Use_ibaPADU-S-CM_DI" Value="true"/>
<Property Name="Use_Output_StatusSignals" Value="false"/>

```

In the example above, the offset must be in the range of 0...63 when FO configuration "Int64" is used. The offset of 128 is outside of this range and therefore the configuration becomes invalid.

14 Support and contact

Support

Phone: +49 911 97282-14
Email: support@iba-ag.com

Note



If you need support for software products, please state the number of the license container. For hardware products, please have the serial number of the device ready.

Contact

Headquarters

iba AG
Koenigswarterstrasse 44
90762 Fuerth
Germany

Phone: +49 911 97282-0
Email: iba@iba-ag.com

Mailing address

iba AG
Postbox 1828
D-90708 Fuerth, Germany

Delivery address

iba AG
Gebhardtstrasse 10
90762 Fuerth, Germany

Regional and Worldwide

For contact data of your regional iba office or representative please refer to our web site:

www.iba-ag.com