



# ibaPDA-Interface-CAN

## Data Interface for CAN bus

Manual

Issue 1.0

Measurement Systems for Industry and Energy

[www.iba-ag.com](http://www.iba-ag.com)

---

## Manufacturer

iba AG  
Koenigswarterstrasse 44  
90762 Fuerth  
Germany

## Contacts

Main office    +49 911 97282-0  
Support        +49 911 97282-14  
Engineering    +49 911 97282-13  
E-mail         iba@iba-ag.com  
Web             www.iba-ag.com

Unless explicitly stated to the contrary, it is not permitted to pass on or copy this document, nor to make use of its contents or disclose its contents. Infringements are liable for compensation.

© iba AG 2025, All rights reserved.

The content of this publication has been checked for compliance with the described hardware and software. Nevertheless, discrepancies cannot be ruled out, and we do not provide guarantee for complete conformity. However, the information furnished in this publication is updated regularly. Required corrections are contained in the following regulations or can be downloaded on the Internet.

The current version is available for download on our web site [www.iba-ag.com](http://www.iba-ag.com).

Version	Date	Revision	Author	Version SW
1.0	10-2025	First edition	nm	8.12.0

Windows® is a brand and registered trademark of Microsoft Corporation. Other product and company names mentioned in this manual can be labels or registered trademarks of the corresponding owners.

## Contents

<b>1</b>	<b>About this documentation .....</b>	<b>4</b>
1.1	Target group and previous knowledge .....	4
1.2	Notations .....	4
1.3	Used symbols.....	5
<b>2</b>	<b>System requirements .....</b>	<b>6</b>
<b>3</b>	<b>CAN interface .....</b>	<b>7</b>
3.1	System topologies.....	7
3.2	Configuration and engineering ibaPDA.....	8
3.2.1	Interface settings .....	8
3.2.2	Adding a module.....	9
3.2.3	General module settings.....	10
3.2.4	Connection settings .....	11
3.2.5	Signal configuration .....	12
<b>4</b>	<b>Diagnostics.....</b>	<b>14</b>
4.1	License .....	14
4.2	Visibility of the interface.....	14
4.3	Log files.....	15
4.4	Connection diagnostics with PING.....	16
4.5	Connection table .....	17
4.6	Diagnostic modules .....	18
<b>5</b>	<b>Appendix .....</b>	<b>23</b>
5.1	Configuration of the CAN gateway .....	23
<b>6</b>	<b>Support and contact.....</b>	<b>27</b>

# 1 About this documentation

This documentation describes the function and application of the software interface *ibaPDA-Interface-CAN*.

## Other documentation



This documentation is a supplement to the *ibaPDA* manual. Information about all the other characteristics and functions of *ibaPDA* can be found in the *ibaPDA* manual or in the online help.

## 1.1 Target group and previous knowledge

This documentation is aimed at qualified professionals who are familiar with handling electrical and electronic modules as well as communication and measurement technology. A person is regarded as professional if he/she is capable of assessing safety and recognizing possible consequences and risks on the basis of his/her specialist training, knowledge and experience and knowledge of the standard regulations.

For the handling of *ibaPDA-Interface-CAN* the following basic knowledge is required and/or useful:

- Basic knowledge of *ibaPDA*
- Knowledge of configuration and operation of the relevant measuring devices/measuring systems

## 1.2 Notations

In this manual, the following notations are used:

Action	Notation
Menu command	Menu <i>Logic diagram</i>
Calling the menu command	<i>Step 1 – Step 2 – Step 3 – Step x</i> Example: Select the menu <i>Logic diagram – Add – New function block</i> .
Keys	<Key name> Example: <Alt>; <F1>
Press the keys simultaneously	<Key name> + <Key name> Example: <Alt> + <Ctrl>
Buttons	<Key name> Example: <OK>; <Cancel>
Filenames, paths	<i>Filename, Path</i> Example: <i>Test.docx</i>

## 1.3 Used symbols

If safety instructions or other notes are used in this manual, they mean:

---

### Danger!



**The non-observance of this safety information may result in an imminent risk of death or severe injury:**

- Observe the specified measures.
- 

### Warning!



**The non-observance of this safety information may result in a potential risk of death or severe injury!**

- Observe the specified measures.
- 

### Caution!



**The non-observance of this safety information may result in a potential risk of injury or material damage!**

- Observe the specified measures
- 

### Note



A note specifies special requirements or actions to be observed.

---

### Tip



Tip or example as a helpful note or insider tip to make the work a little bit easier.

---

### Other documentation



Reference to additional documentation or further reading.

---

## 2 System requirements

The following system requirements are necessary for the use of the CAN data interface:

### Software

- *ibaPDA* v8.12.0 or higher

- License for *ibaPDA-Interface-CAN*  
for up to 2 connections to Ethernet/CAN gateways

If you need more than 2 connections, you will require additional *one-step-up-Interface-CAN* licenses for each additional 2 connections. A total of up to 256 connections are possible.

For further requirements for the used computer hardware and the supported operating systems, refer to the *ibaPDA* documentation.

### Hardware

The following Ethernet/CAN gateways are currently supported:

- CAN-Ethernet gateway (2 channels) from iba (art. no. 19.000040)
- Ethernet/CAN Gateway EtherCAN CI-ARM9/RMD-IBA of EMS Thomas Wünsche (art. no. 12-20-383-20)

Ethernet/CAN interface with 32-bit microcontroller (ARM9 core) and two internal CAN controllers, preconfigured for iba AG

### License information

Order no.	Product name	Description
31.001027	ibaPDA-Interface-CAN	<i>ibaPDA</i> data interface for connecting CAN gateways, up to 2 connections possible
31.101027	one-step-up-Interface-CAN	Extension license for 2 additional connections Maximum 256 connections possible

## 3 CAN interface

The CAN interface is suitable for data acquisition from a CAN bus (Controller Area Network) as a data source. The interface was developed as a successor to the *ibaBM-CAN* device and replaces it.

The following devices are currently supported:

- CAN Ethernet gateway (2-channel) from iba (art. no. 19.000040)
- Ethernet/CAN-Gateway EtherCAN CI-ARM9/RMD-IBA of the manufacturer EMS Thomas Wünsche (art. no. 12-20-383-20)

Ethernet/CAN interface with 32-bit microcontroller (ARM9 core) and two internal CAN controllers, preconfigured for iba AG


### Other documentation



Further information can be found on the manufacturer's website:  
<https://www.ems-wuensche.com>

### 3.1 System topologies

A CAN-Ethernet gateway is used to establish the connection between the CAN bus and *ibaPDA*. This means that the Ethernet network interface can simply be used on the *ibaPDA* side.



The device has two CAN bus connections so that communication with two CAN bus networks is possible with one device. The interface license allows up to two connections.


For easier configuration of the measurement data, the interface offers automatic detection of active CAN bus devices.

## 3.2 Configuration and engineering ibaPDA

The engineering for *ibaPDA* is described in the following. If all system requirements are fulfilled, *ibaPDA* displays the *CAN* interface in the signal tree of the I/O Manager.

### 3.2.1 Interface settings

The interface has the following functions and configuration options:



#### Set all values to zero when the connection to a device is lost

If this option is enabled, all measured values of a device are set to zero as soon as the connection is lost. If this option is disabled, *ibaPDA* will keep the last valid measured value at the time the connection was lost in the memory.

#### Start acquisition even if a device is not accessible

If this option is enabled, the acquisition will start even if *ibaPDA* was not able to establish a connection to a device or if there is an error in the configuration. In case of an error, a warning is indicated in the validation dialog. If the system has been started without a connection to the device, *ibaPDA* will periodically try to connect to the device.

#### <Open log file>

Messages relating to the interface are written to a separate log file. To open the current log file, click on <Open log file>.

#### <Reset statistics>

Click this button to reset the calculated times and error counters in the table to 0.

#### Connection table

For each connection, the table shows the connection status, the current values for the update time (actual value, average, min. and max.) as well as the data size. In addition, there is an error counter for the individual connections during the acquisition.



### Connection table

For each connection, the table shows the connection status, the number of messages received and an error counter for the individual connections during the measurement.


For more information on the connection table, see ➤ *Connection table*, page 17.

## 3.2.2 Adding a module

Add a *CAN* module for each CAN connection.

### Procedure

1. Click on the blue link *Click to add module* located under each data interface in the *Inputs* or *Outputs* tab.
2. Select the desired module type in the dialog box and assign a name via the input field if required.
3. Confirm the selection with <OK>.



### 3.2.3 General module settings

To configure a module, select it in the tree structure.

All modules have the following setting options.

**CAN (7)**

**CAN General** Connection Analog Digital

**Basic**

Module Type	CAN
Locked	None
Enabled	True
Name	CAN
Comment	
Module No.	7
Timebase	10 ms
Use module name as prefix	False

**Module Layout**

No. analog signals	32
No. digital signals	32

**Name**  
The name of the module.

#### Basic settings

##### Module Type (information only)

Indicates the type of the current module.

##### Locked

You can lock a module to avoid unintentional or unauthorized changing of the module settings.

##### Enabled

Enable the module to record signals.

##### Name

You can enter a name for the module here.

##### Comment

You can enter a comment or description of the module here. This will be displayed as a tooltip in the signal tree.

##### Module No.

This internal reference number of the module determines the order of the modules in the signal tree of *ibaPDA* client and *ibaAnalyzer*.

##### Timebase

All signals of the module are sampled on this timebase.

##### Use module name as prefix

This option puts the module name in front of the signal names.


## Module Layout

### No. analog signals/No. digital signals

Define the number of configurable analog and digital signals in the signal tables. The default value is 32 for each. The maximum value is 1000. The signal tables are adjusted accordingly.

## 3.2.4 Connection settings

Configure and test the connection to the respective CAN gateway in the *Connection* tab.



## Connection

### Address

Enter the IP address or the host name of the CAN gateway.

### Port

Port via which *ibaPDA* is to receive data

### CAN timeout

Here you can specify a value for the timeout in seconds for establishing the connection and for read accesses. If the time set here is exceeded, *ibaPDA* declares the device unavailable.

### <Test>

If you click on this button, the connection to the specified IP address is tested. *ibaPDA* also attempts to open the specified ports and read some information from the device.

*ibaPDA* scans the bus for 3 seconds and displays the CAN IDs found. *ibaPDA* asks if you want to add analog signals for the CAN ID data when you click on one of the CAN IDs.

For further information see [➤ Signal configuration](#), page 12.

### 3.2.5 Signal configuration

In the *Analog* and *Digital* tabs, you can configure the signals for the CAN gateways

#### Other documentation



Detailed descriptions of the columns and how to fill in the signal tables can be found in the documentation for *ibaPDA*.

#### Analog and Digital tab

Name	Unit	Gain	Offset	CAN ID	Address	Bit no.	Length (bit)	DataType	Active	Actual
0 Accelerator Pedal 1 Low Idle Switch		1	0	0xCF00300	0	0	2	BYTE	<input checked="" type="checkbox"/>	3
1 Accelerator Pedal Kickdown Switch		1	0	0xCF00300	0	2	2	BYTE	<input checked="" type="checkbox"/>	3
2 Road Speed Limit Status		1	0	0xCF00300	0	4	2	BYTE	<input checked="" type="checkbox"/>	3
3 Accelerator Pedal 2 Low Idle Switch		1	0	0xCF00300	0	6	2	BYTE	<input checked="" type="checkbox"/>	3
4 Accelerator Pedal Position 1		1	0	0xCF00300	1	0	8	BYTE	<input checked="" type="checkbox"/>	36
5 Engine Percent Load At Current Speed		1	0	0xCF00300	2	0	8	BYTE	<input checked="" type="checkbox"/>	255
6 Remote Accelerator Pedal Position		1	0	0xCF00300	3	0	8	BYTE	<input checked="" type="checkbox"/>	255
7 Accelerator Pedal Position 2		1	0	0xCF00300	4	0	8	BYTE	<input checked="" type="checkbox"/>	255
8 Vehicle Acceleration Rate Limit Status		1	0	0xCF00300	5	0	2	BYTE	<input checked="" type="checkbox"/>	3
9 Actual Maximum Available - Percent T...		1	0	0xCF00300	6	0	16	BYTE	<input checked="" type="checkbox"/>	255
10 Engine Torque Mode		1	0	0xCF00400	0	0	4	BYTE	<input checked="" type="checkbox"/>	15
11 Driver's Demand Engine - Percent Tor...		1	0	0xCF00400	1	0	8	BYTE	<input checked="" type="checkbox"/>	255
12 Actual Engine - Percent Torque		1	0	0xCF00400	2	0	8	BYTE	<input checked="" type="checkbox"/>	255
13 Engine Speed		1	0	0xCF00400	3	0	16	BYTE	<input checked="" type="checkbox"/>	192
14 Source Address of Controlling device		1	0	0xCF00400	5	0	8	BYTE	<input checked="" type="checkbox"/>	255
15 Engine Starter Mode		1	0	0xCF00400	6	4	8	BYTE	<input checked="" type="checkbox"/>	240
16 Engine Demand - Percent Torque		1	0	0xCF00400	7	0	8	BYTE	<input checked="" type="checkbox"/>	255
17 Driver 1 working state		1	0	0xCFE6C00	0	0	3	BYTE	<input checked="" type="checkbox"/>	7
18 Driver 2 working state		1	0	0xCFE6C00	0	3	3	BYTE	<input checked="" type="checkbox"/>	7
19 Vehicle motion		1	0	0xCFE6C00	0	6	2	BYTE	<input checked="" type="checkbox"/>	3
20 Driver 1 Time Related States		1	0	0xCFE6C00	1	0	4	BYTE	<input checked="" type="checkbox"/>	15
21 Driver card, driver 1		1	0	0xCFE6C00	1	4	2	BYTE	<input checked="" type="checkbox"/>	3
22 Vehicle Overspeed		1	0	0xCFE6C00	1	6	2	BYTE	<input checked="" type="checkbox"/>	3
23 Driver 2 Time Related States		1	0	0xCFE6C00	2	0	4	BYTE	<input checked="" type="checkbox"/>	15

#### Name

Enter a meaningful plain text name for the signal.

#### Unit (analog signals only)

Assignment of a physical unit for the signal

You can enter a maximum of 11 characters, the field is only considered a comment field. The unit is always displayed in conjunction with a numerical display of the values.

#### Gain, Offset (analog signals only)

Specification of gain and offset for scaling the incoming values

The values describe a linear characteristic curve for scaling. If incoming values are specified in physical units, you can ignore this function, i.e. Gain = 1 and Offset = 0.

#### CAN ID

ID of the associated CAN message

#### Address

Byte address within the 8 data bytes of a CAN message

**Length (bit) (analog signals only)**

Length of the message in bits

If you change the data type, this length changes automatically if it was equal to the bit length of the data type. It can be used to use only a few bits of a byte.

**Data type (analog signals only)**

Selection of the data type of the signal

The data type determines the address of the next signal.

**Active**

Activation or deactivation of the respective signal

**Actual**


Display of the current actual value of the signal

## 4 Diagnostics

### 4.1 License

If the interface is not displayed in the signal tree, you can either check in *ibaPDA* in the I/O Manager under *General – Settings* or in the *ibaPDA* service status application whether your license for the interface *ibaPDA-Interface-CAN* has been properly recognized. The number of licensed connections is shown in brackets.

The figure below shows the license for the *Codesys Xplorer* interface as an example.



### 4.2 Visibility of the interface

If the interface is not visible despite a valid license, it may be hidden.

Check the settings in the *General* tab in the *Interfaces* node.


#### Visibility

The table *Visibility* lists all the interfaces that are available either through licenses or installed cards. These interfaces can also be viewed in the interface tree.

You can hide or display the interfaces not required in the interface tree by using the checkbox in the *Visible* column.

Interfaces with configured modules are highlighted in green and cannot be hidden.

Selected interfaces are visible, the others are hidden:



## 4.3 Log files

If connections to target platforms or clients have been established, all connection-specific actions are logged in a text file. You can open this (current) file and, e.g., scan it for indications of possible connection problems.

You can open the log file via the button <Open log file>. The button is available in the I/O Manager:

- for many interfaces in the respective interface overview
- for integrated servers (e.g. OPC UA server) in the *Diagnostics* tab.

In the file system on the hard drive, you can find the log files of the *ibaPDA* server (...\\ProgramData\\iba\\ibaPDA\\Log). The file names of the log files include the name or abbreviation of the interface type.

Files named `interface.txt` are always the current log files. Files named `Interface_yyyy_mm_dd_hh_mm_ss.txt` are archived log files.

Examples:

- `ethernetipLog.txt` (log of EtherNet/IP connections)
- `AbEthLog.txt` (log of Allen-Bradley Ethernet connections)
- `OpcUAServerLog.txt` (log of OPC UA server connections)

## 4.4 Connection diagnostics with PING

PING is a system command with which you can check if a certain communication partner can be reached in an IP network.

1. Open a Windows command prompt.



2. Enter the command "ping" followed by the IP address of the communication partner and press <ENTER>.

→ With an existing connection you receive several replies.

A screenshot of the Windows Command Prompt window titled 'Administrator: Command Prompt'. The window shows the following text:

```
Microsoft Windows [Version 10.0]
(c) Microsoft Corporation. All rights reserved.

C:\Windows\system32>ping 192.168.81.10

Pinging 192.168.81.10 with 32 bytes of data:
Reply from 192.168.81.10: bytes=32 time=1ms TTL30
Reply from 192.168.81.10: bytes=32 time<1ms TTL30
Reply from 192.168.81.10: bytes=32 time<1ms TTL30
Reply from 192.168.81.10: bytes=32 time<1ms TTL30

Ping statistics for 192.168.81.10:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 1ms, Average = 0ms

C:\Windows\system32>
```

→ With no existing connection you receive error messages.

A screenshot of the Windows Command Prompt window titled 'Administrator: Command Prompt'. The window shows the following text:

```
Microsoft Windows [Version 10.0]
(c) Microsoft Corporation. All rights reserved.

C:\Windows\system32>ping 192.168.81.10

Pinging 192.168.81.10 with 32 bytes of data:
Reply from 192.168.81.10: Destination host unreachable.
Reply from 192.168.81.10: Destination host unreachable.
Reply from 192.168.81.10: Destination host unreachable.
Reply from 192.168.81.10: Destination host unreachable.


Ping statistics for 192.168.81.10:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),

C:\Windows\system32>
```



## 4.5 Connection table

The CAN interface shows all configured connections to CAN gateways in a table. There is one row per connection to a gateway.



The table columns and their meaning:

- Name: Name of the module
- Address: IP Address or Host Name of the Gateways
- Error: Number of communication errors that occurred

Counts up if the connection attempt to a gateway fails or the gateway reports an error to the CAN bus.

- Messages: Number of the received messages
- CAN IDs Number of different CAN ID messages received

Additional information is provided by the background color of the table rows:

Color	Meaning
Green	The connection is OK and the data is read.
Red	The connection is not active.
Gray	No connection configured.

## 4.6 Diagnostic modules

Diagnostic modules are available for most Ethernet based interfaces and Xplorer interfaces. Using a diagnostic module, information from the diagnostic displays (e.g. diagnostic tabs and connection tables of an interface) can be acquired as signals.


A diagnostic module is always assigned to a data acquisition module of the same interface and supplies its connection information. By using a diagnostic module, you can record and analyze the diagnostic information continuously in the *ibaPDA* system.

Diagnostic modules do not consume any license connections because they do not establish their own connection but refer to another module.

Example for the use of diagnostic modules:


- A notification can be generated, whenever the error counter of a communication connection exceeds a certain value or the connection gets lost.
- In case of a disturbance, the current response times in the telegram traffic may be documented in an incident report.
- The connection status can be visualized in *ibaQPanel*.
- You can forward diagnostic information via the SNMP server integrated in *ibaPDA* or via OPC DA/UA server to superordinate monitoring systems like network management tools.

In case the diagnostic module is available for an interface, a "Diagnostics" module type is shown in the *Add module* dialog (example: Generic TCP).



## Module settings diagnostic module

For a diagnostic module, you can make the following settings (example: Generic TCP):



**General** Analog Digital

**Basic**

Module Type	Diagnostics
Locked	None
Enabled	True
Name	Generic TCP Diagnostics
Comment	
Module No.	7
Timebase	10 ms
Use module name as prefix	False

**Diagnostics**


Target module	Generic TCP (58)
---------------	------------------

**Target module**  
The number of the module of which the diagnostic data should be measured.

The basic settings of a diagnostic module equal those of other modules.

There is only one setting which is specific for the diagnostic module: the target module.

By selecting the target module, you assign the diagnostic module to the module on which you want to acquire information about the connection. You can select the supported modules of this interface in the drop-down list of the setting. You can assign exactly one data acquisition module to each diagnostic module. When having selected a module, the available diagnostic signals are immediately added to the *Analog* and *Digital* tabs. It depends on the type of interface, which signals exactly are added. The following example lists the analog values of a diagnostic module for a Generic TCP module.



	Name	Unit	Gain	Offset	Active	Actual
0	IP address (part 1)		1	0	<input checked="" type="checkbox"/>	
1	IP address (part 2)		1	0	<input checked="" type="checkbox"/>	
2	IP address (part 3)		1	0	<input checked="" type="checkbox"/>	
3	IP address (part 4)		1	0	<input checked="" type="checkbox"/>	
4	Port		1	0	<input checked="" type="checkbox"/>	
5	Message counter		1	0	<input checked="" type="checkbox"/>	
6	Incomplete errors		1	0	<input checked="" type="checkbox"/>	
7	Packet size (actual)	bytes	1	0	<input checked="" type="checkbox"/>	
8	Packet size (max)	bytes	1	0	<input checked="" type="checkbox"/>	
9	Time between data (actual)	ms	1	0	<input checked="" type="checkbox"/>	
10	Time between data (min)	ms	1	0	<input checked="" type="checkbox"/>	

For example, the IP (v4) address of a Generic TCP module (see fig. above) will always be split into 4 parts derived from the dot-decimal notation, for better reading. Also other values are being determined, as there are port number, counters for telegrams and errors, data sizes and telegram cycle times. The following example lists the digital values of a diagnostic module for a Generic TCP module.



	Name	Active	Actual
0	Active connection mode	<input checked="" type="checkbox"/>	
1	Invalid packet	<input checked="" type="checkbox"/>	
2	Connecting	<input checked="" type="checkbox"/>	
3	Connected	<input checked="" type="checkbox"/>	

## Diagnostic signals

Depending on the interface type, the following signals are available:

Signal name	Description
Active	Only relevant for redundant connections. Active means that the connection is used to measure data, i.e. for redundant standby connections the value is 0. For normal/non-redundant connections, the value is always 1.
Buffer file size (actual/avg/max)	Size of the file for buffering statements
Buffer memory size (actual/avg/max)	Size of the memory used by buffered statements
Buffered statements	Number of unprocessed statements in the buffer
Buffered statements lost	Number of buffered but unprocessed and lost statements
Connected	Connection is established
Connected (in)	A valid data connection for the reception (in) is available
Connected (out)	A valid data connection for sending (out) is available
Connecting	Connection being established
Connection attempts (in)	Number of attempts to establish the receive connection (in)
Connection attempts (out)	Number of attempts to establish the send connection (out)
Connection ID O->T	ID of the connection for output data (from the target system to <i>ibaPDA</i> ). Corresponds to the assembly instance number
Connection ID T->O	ID of the connection for input data (from <i>ibaPDA</i> to target system). Corresponds to the assembly instance number
Connection phase (in)	Status of the ibaNNet-E data connection for reception (in)
Connection phase (out)	Status of the ibaNNet-E data connection for sending (out)
Connections established (in)	Number of currently valid data connections for reception (in)
Connections established (out)	Number of currently valid data connections for sending (out)
Data length	Length of the data message in bytes
Data length O->T	Size of the output message in byte
Data length T->O	Size of the input message in byte
Destination IP address (part 1-4) O->T	4 octets of the IP address of the target system Output data (from target system to <i>ibaPDA</i> )
Destination IP address (part 1-4) T->O	4 octets of the IP address of the target system Input data (from <i>ibaPDA</i> to target system)
Disconnects (in)	Number of currently interrupted data connections for reception (in)
Disconnects (out)	Number of currently interrupted data connections for sending (out)
Error counter	Communication error counter
Exchange ID	ID of the data exchange
Incomplete errors	Number of incomplete messages

Signal name	Description
Incorrect message type	Number of received messages with wrong message type
Input data length	Length of data messages with input signals in bytes ( <i>ibaPDA</i> receives)
Invalid data points	Number of received data points with missing configuration
Invalid packet	Invalid data packet detected
IP address (part 1-4)	4 octets of the IP address of the target system
Keepalive counter	Number of Keepalive messages received by the OPC UA Server
Lost images	Number of lost images (in) that were not received even after a retransmission
Lost Profiles	Number of incomplete/incorrect profiles
Message counter	Number of messages received
Messages per cycle	Number of messages in the cycle of the update time
Messages received since configuration	Number of received data telegrams (in) since start of acquisition
Messages received since connection start	Number of received data telegrams (in) since the start of the last connection setup. Reset with each connection loss.
Messages sent since configuration	Number of sent data telegrams (out) since start of acquisition
Messages sent since connection start	Number of sent data telegrams (out) since the start of the last connection setup. Reset with each connection loss.
Multicast join error	Number of multicast login errors
Number of request commands	Counter for request messages from <i>ibaPDA</i> to the PLC/CPU
Output data length	Length of the data messages with output signals in bytes ( <i>ibaPDA</i> sends)
Packet size (actual)	Size of the currently received message
Packet size (max)	Size of the largest received message
Ping time (actual)	Response time for a ping telegram
Port	Port number for communication
Producer ID (part 1-4)	Producer ID as 4-byte unsigned integer
Profile Count	Number of completely recorded profiles
Read counter	Number of read accesses/data requests
Receive counter	Number of messages received
Response time (actual/average/max/min)	<p>Response time is the time between measured value request from <i>ibaPDA</i> and response from the PLC or reception of the data.</p> <p>Actual: current value</p> <p>Average/max/min: static values of the update time since the last start of the acquisition or reset of the counters.</p>
Retransmission requests	Number of data messages requested again if lost or delayed

Signal name	Description
Rows (last)	Number of resulting rows by the last SQL query (within the configured range of result rows)
Rows (maximum)	Maximum number of resulting rows by any SQL query since the last start of acquisition (possible maximum equals the configured number of result rows)
Send counter	Number of send messages
Sequence errors	Number of sequence errors
Source IP address (part 1-4) O->T	4 octets of the IP address of the target system Output data (from target system to <i>ibaPDA</i> )
Source IP address (part 1-4) T->O	4 octets of the IP address of the target system Input data (from <i>ibaPDA</i> to target system)
Statements processed	Number of executed statements since last start of acquisition
Synchronization	Device is synchronized for isochronous acquisition
Time between data (actual/ max/min)	Time between two correctly received messages  Actual: between the last two messages  Max/min: statistical values since start of acquisition or reset of counters
Time offset (actual)	Measured time difference of synchronicity between <i>ibaPDA</i> and the <i>ibaNet-E</i> device
Topics Defined	Number of defined topics
Topics Updated	Number of updated topics
Unknown sensor	Number of unknown sensors
Update time (actual/average/ configured/max/min)	Specifies the update time in which the data is to be retrieved from the PLC, the CPU or from the server (configured). Default is equal to the parameter "Timebase". During the measurement, the real actual update time can be higher than the set value if the PLC needs more time to transfer the data. How fast the data is really updated, you can check in the connection table. The minimum achievable update time is influenced by the number of signals. The more signals are acquired, the greater the update time becomes.  Average/max/min: static values of the update time since the last start of the acquisition or reset of the counters.
Write counter	Number of successful write accesses
Write lost counter	Number of failed write accesses

## 5 Appendix

### 5.1 Configuration of the CAN gateway

All relevant CAN gateway settings can be accessed via a web server on the device. Information on opening the web server can be found in the manufacturer's documentation.

1. Log in with the initial access data:

- User: admin
- Password: admin

---


#### Note



For security reasons, iba strongly recommends to change your password immediately. This change will take effect with the next login attempt.

---

→ The following window appears:



2. Open *Network configuration – Validate – IP settings* and make the following settings:

The screenshot shows a web browser window with the title 'EtherCAN-ARM9'. The address bar shows a URL starting with '/cgi-bin/basicco...'. The page content includes the text 'EMS Dr. Thomas Wuensche' at the top. Below this is a horizontal blue line, followed by the title 'EtherCAN-ARM9' in bold, also preceded by a horizontal blue line. Underneath is the section 'Current Values' which lists: IP Address= 192.168., Netmask= 255.255.255.0, Gateway= 192.168., and Nameserver= 192.168.. Below this is a section titled 'Change values' in green. It contains four input fields: 'IP address' with '192.168.', 'Netmask' with '255.255.255.0', 'Gateway' with '192.168.', and 'Nameserver' with '192.168.'. At the bottom of this section are two buttons: 'Validate changes' and 'Clear'. Below these is a button labeled 'Go to main menu'. The entire form is enclosed in a horizontal blue line at the bottom.

EMS Dr. Thomas Wuensche

---

## EtherCAN-ARM9

---

**Current Values**

IP Address= 192.168.

Netmask= 255.255.255.0

Gateway= 192.168.

Nameserver= 192.168.

**Change values**

IP address

Netmask

Gateway

Nameserver

---



### 3. Open *CAN Configuration – CAN bus Baudrate* and make the following settings:

EMS Dr. Thomas Wuensche

---

## EtherCAN-ARM9

---

**Current Values**

canrv 0 is: Server - Listening on port 1501, baud rate set to: 250  
 canrv 1 is: Server - Listening on port 1502, baud rate set to: 250

**Change values**

**canrv0:**

If enabled, canrv will be started at boot time. ☒ Start at boot

Port number

Baudrate

Baud rate is not mandatory for a server.  
 But when set it cannot be overwritten by the client.

Keep alive is mandatory, if another EtherCAN device is client! ☒ Keep Alive

**canrv1:**

If enabled, canrv will be started at boot time. ☒ Start at boot

Port number

Baudrate

Baud rate is not mandatory for a server.  
 But when set it cannot be overwritten by the client.

Keep alive is mandatory, if another EtherCAN device is client! ☒ Keep Alive

Supported baudrates 10-20-25-50-100-125-250-500-800-1000 [kBaud]

---

EMS Dr. Thomas Wuensche +49-8441-490260 - support@ems-wuensche.com  
 www.ems-wuensche.com

### 4. Save the changes and restart the device.

It is not usually necessary to adjust the other parameters.

### Default configuration

The default delivery of EtherCAN CI has the following parameters set:

<b>IP address</b>	192.168.1.15
<b>Netmask</b>	255.255.255.0
<b>Gateway</b>	none
<b>Nameserver</b>	none

CAN driver selection	EMS driver
<b>CAN 1</b>	Server Port: 1501 Start at boot: enabled Keep alive: enabled Baudrate: 250 kBaud
<b>CAN 2</b>	Server Port: 1502 Start at boot: enabled Keep alive: enabled Baudrate: 250 kBaud

## 6 Support and contact

### Support

Phone: +49 911 97282-14  
Email: [support@iba-ag.com](mailto:support@iba-ag.com)

---

#### Note



If you need support for software products, please state the number of the license container. For hardware products, please have the serial number of the device ready.

---

### Contact

#### Headquarters

iba AG  
Koenigswarterstrasse 44  
90762 Fuerth  
Germany

Phone: +49 911 97282-0  
Email: [iba@iba-ag.com](mailto:iba@iba-ag.com)

#### Mailing address

iba AG  
Postbox 1828  
D-90708 Fuerth, Germany

#### Delivery address

iba AG  
Gebhardtstrasse 10  
90762 Fuerth, Germany

#### Regional and Worldwide

For contact data of your regional iba office or representative please refer to our web site:

**[www.iba-ag.com](http://www.iba-ag.com)**